

# Contraction of the second

### CCD area image sensor

S13240/S13241 series S10140/S10141 series (-01)

## Low readout noise, high resolution (pixel size: 12 µm)

The S13240/S13241 series and S10140/S10141 series (-01) are back-thinned FFT-CCD area image sensors developed for low-lightlevel detection. By using the binning operation, they can be used as a linear image sensor having a vertically long photosensitive area. This makes them suited for use in spectrophotometry. The binning operation offers significant improvement in S/N and signal processing speed compared with conventional methods by which signals are digitally added by an external circuit. These products feature low noise and low dark current (MPP mode operation). This allows low-light-level detection by making the integration time longer. And, wide dynamic range has been achieved by increasing the saturation charge than that of the previous product (S10140/S10141 series).

The S13240/S13241 series is a high-speed readout type, and the S10140/S10141 series (-01) is a low noise type. These products have an pixel size of  $12 \times 12 \mu m$  and are available in the photosensitive area ranging from 24.576 (H) × 1.464 (V) mm<sup>2</sup> (2048 × 122 pixels) to 24.576 (H) × 6.072 (V) mm<sup>2</sup> (2048 × 506 pixels).

#### Features

- Wide dynamic range
- Low readout noise: 4 e<sup>-</sup> rms typ. [S10140/S10141 series (-01)] 30 e<sup>-</sup> rms typ. (S13240/S13241 series)
- High resolution: pixel size 12 × 12 μm
- Non-cooled type: S13240 series, S10140 series (-01) One-stage TE-cooled type: S13241 series, S10141 series (-01)
- Quantum efficiency: 90% or higher at peak
- **Wide spectral response range**
- MPP operation
- High UV sensitivity and stable characteristics under UV light irradiation
- Pin compatible with the S7030/S7031 series [S10140/S10141 series (-01)]

#### Selection guide

#### Applications

- Fluorescence spectrophotometry, ICP
- Industrial product inspection
- Semiconductor inspection
- DNA sequencer
- Low-light-level detection
- Raman spectroscopy

Type no.	Cooling	Readout speed max.	Total number of pixels	Number of effective pixels	Image size
турс по.	Cooling	(MHz)	$(H) \times (V)$	$(H) \times (V)$	mm (H) $\times$ mm (V)
S13240-1107			2068 × 128	2048 × 122	24.576 × 1.464
S13240-1108	Non-cooled	10	2068 × 256	2048 × 250	24.576 × 3.000
S13240-1109			2068 × 512	2048 × 506	24.576 × 6.072
S13241-1107S			2068 × 128	2048 × 122	24.576 × 1.464
S13241-1108S	One-stage TE-cooled	10	2068 × 256	2048 × 250	24.576 × 3.000
S13241-1109S			2068 × 512	2048 × 506	24.576 × 6.072
S10140-1107-01			2068 × 128	2048 × 122	24.576 × 1.464
S10140-1108-01	Non-cooled	0.5	2068 × 256	2048 × 250	24.576 × 3.000
S10140-1109-01			2068 × 512	2048 × 506	24.576 × 6.072
S10141-1107S-01			2068 × 128	2048 × 122	24.576 × 1.464
S10141-1108S-01	One-stage TE-cooled	0.5	2068 × 256	2048 × 250	24.576 × 3.000
S10141-1109S-01			2068 × 512	2048 × 506	24.576 × 6.072

Note: S10142 series (-01) [Two-stage TE-cooled type] is available upon request (made-to-order products).

1

#### Structure

Parameter	S13240 series	S13241 series	S10140 series (-01)	S10141 series (-01)			
Pixel size (H $\times$ V)	12 × 12 µm						
Vertical clock		2-pł	nase				
Horizontal clock		2-pł	nase				
Output circuit	Two-stage MOSF	ET source follower	One-stage MOSFI	ET source follower			
Package	24-pin ceramic DIP (refer to dimensional outlines)						
Window material*1	Quartz glass* <sup>2</sup>	AR-coated sapphire* <sup>3</sup>	Quartz glass* <sup>2</sup>	AR-coated sapphire* <sup>3</sup>			

\*1: Temporary window type (ex. S13240-1107N) can also be provided.

\*2: Resin sealing

\*3: Hermetic sealing

#### Absolute maximum ratings (Ta=25 °C)

Down	meter	Cumbol	Min.	Turp	Max.	Unit
		Symbol		Тур.		
Operating tempera		Topr	-50	-	+50	°C
Storage temperatu	1	Tstg	-50	-	+70	°C
Output transistor	S13240/S13241 series	Vod	-0.5	-	+20	v
drain voltage	S10140/S10141 series (-01)	VOD	-0.5	-	+25	v
Reset drain voltage	е	Vrd	-0.5	-	+18	V
Output amplifier return voltage	S13240/S13241 series	Vret	-0.5	-	+18	V
Horizontal input so	ource voltage	VISH	-0.5	-	+18	V
Vertical input gate voltage		VIG1V, VIG2V	-11	-	+15	V
Horizontal input ga	Horizontal input gate voltage		-11	-	+15	V
Summing gate vol	tage	Vsg	-11	-	+15	V
Output gate voltag	je	Vog	-11	-	+15	V
Reset gate voltage	2	Vrg	-11	-	+15	V
Transfer gate volta	ige	Vtg	-11	-	+15	V
Vertical shift regist	er clock voltage	VP1V, VP2V	-11	-	+15	V
Horizontal shift reg	gister clock voltage	Vp1H, Vp2H	-11	-	+15	V
Soldering condition	ns*5	Tsol	260 °C, within 5	s, at least 2 mm away	from lead roots	-
Maximum current of built-in TE-cooler* <sup>6</sup>		Imax	-	-	3.0	А
Maximum voltage	of built-in TE-cooler	Vmax	-	-	3.6	V
Maximum tempera radiation side	ture of heat	-	-	-	70	°C

Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.

\*4: Package temperature [S13240 series, S10140 series (-01)], chip temperature [S13241 series, S10141 series (-01)]

\*5: Use a soldering iron.

\*6: When the current value exceeds Imax, the heat absorption begins to decrease due to the Joule heat. This maximum current Imax is not the threshold for damaging the thermoelectric cooler. To protect the thermoelectric cooler and maintain stable operation, the supply current should be less than 60% of this maximum current.



#### Operating conditions (MPP mode, Ta=25 °C)

Paramete	0r		Sumbol	S1324	ł0/S13241	series	S10140/	S10141 ser	ries (-01)	Unit
Paramete	el		Symbol	Min.	Тур.	Max.	Min.	Тур.	Max.	Onic
Output transistor drain vo	oltage		Vod	14	16	18	20	22	24	V
Reset drain voltage			Vrd	15	16	17	14	15	16	V
Output gate voltage			Vog	3	5	7	3	5	7	V
Substrate voltage			Vss	-	0	-	-	0	-	V
Output amplifier return v	oltage*7		Vret	-	4	5				V
	Input source	e	VISH	-	Vrd	-	-	Vrd	-	
Test point	Vertical gate		VIG1V, VIG2V	-10	-9	-	-10	-9	-	V
	Horizontal gate	input	Vig1h, Vig2h	-10	-9	-	-10	-9	-	
Vertical shift register cloc	k voltago	High	Vp1vh, Vp2vh	1	3	5	1	3	5	V
	.k voltage	Low	VP1VL, VP2VL	-10	-9	-8	-10	-9	-8	v
Horizontal shift register c	lock voltage	High	Vp1hh, Vp2hh	5	7	9	5	7	9	V
	IOCK VOILage	Low	Vp1hl, Vp2hl	-9	-7	-5	-9	-7	-5	v
Summing gate voltage		High	Vsgh	5	7	9	5	7	9	V
		Low	VSGL	-9	-7	-5	-9	-7	-5	v
Reset date voltage		High	Vrgh	8	9	10	8	9	10	V
		Low	Vrgl	-6	-5	-4	-6	-5	-4	V
Transfer gate voltage High Low		High	Vtgh	1	3	5	1	3	5	V
		Low	Vtgl	-10	-9	-8	-10	-9	-8	v
External load resistance			RL	2.0	2.2	2.4	20	22	24	kΩ

\*7: Output amplifier return voltage is a positive voltage with respect to substrate voltage, but the current flows out from the sensor.

#### Electrical characteristics (Ta=25 °C)

Paramete		Sumbol	S1324	I0/S13241	series	S10140/	S10141 ser	ries (-01)	Unit
Paramete	51	Symbol	Min.	Тур.	Max.	Min.	Тур.	Max.	Unit
Output signal frequency*	8	fc	-	2.5	10	-	0.25	0.5	MHz
	-1107 (-01)		-	1600	-	-	1600	-	
Vertical shift register capacitance	-1108 (-01)	CP1V, CP2V	-	3200	-	-	3200	-	pF
capacitance	-1109 (-01)		-	6400	-	-	6400	-	
Horizontal shift register capacitance		Ср1н, Ср2н	-	150	-	-	150	-	pF
Summing gate capacitan	ce	Csg	-	30	-	-	30	-	pF
Reset gate capacitance		Crg	-	30	-	-	30	-	pF
Transfer gate capacitance	9	Ctg	-	70	-	-	70	-	pF
Charge transfer efficiency	CTE	0.99995	0.99999	-	0.99995	0.99999	-	-	
DC output level <sup>*8</sup>		Vout	10	11	12	16	17	18	V
Output impedance*8		Zo	-	0.2	-	-	5	-	kΩ
Power consumption*8 *10		Р	-	100	-	-	16	-	mW

\*8: The values depend on the load resistance (S13240/S13241 series: VoD=16 V, RL=2.2 k $\Omega$ , S10140/S10141 series (-01): VoD=22 V, RL=22 k $\Omega$ )

\*9: Charge transfer efficiency per pixel, measured at half of the saturation output

\*10: Power consumption of the on-chip amp plus load resistance



#### Electrical and optical characteristics (Ta=25 °C, unless otherwise noted)

D	aramatar	Cumbal	S1324	40/S13241	series	S10140/	S10141 ser	ies (-01)	Unit
P	arameter	Symbol	Min.	Тур.	Max.	Min.	Тур.	Max.	
Saturation output vol	tage	Vsat	-	Fw × Sv	-	-	Fw × Sv	-	V
	Vertical		60	70	-	60	70	-	
Full well capacity	Horizontal	Fw	400	500	-	400	500	-	ke⁻
	Summing		400	500	-	400	500	-	]
CCD node sensitivity		Sv	4.5	5.5	6.5	4	5	6	μV/e <sup>-</sup>
Dark current*11	25 °C	DS	-	30	300	-	30	300	o-/nivol/c
MPP mode 0 °C		05	-	3	30	-	3	30	e <sup>-</sup> /pixel/s
Readout noise*12		Nr	-	30	45	-	4	18	e- rms
Dynamic range*13	Line binning	DR	13333	16666	-	100000	125000	-	-
Dynamic range 13	Area scanning	DR	2000	2333	-	15000	20000	-	-
Photoresponse nonur	niformity*14	PRNU	-	±3	±10	-	±3	±10	%
Spectral response rar	λ	-	200 to 1100	-	-	200 to 1100	-	nm	
	Point defect*15 White spots		-	-	0	-	-	0	-
Dlamiah	Black spots	1	-	-	10	-	-	10	-
Blemish	Cluster defect*16	_	-	-	3	-	-	3	-
	Column defect*17		-	-	0	-	-	0	-

\*11: Dark current nearly doubles for every 5 to 7 °C increase in temperature.

\*12: Operating frequency 20 kHz, temperature -50 °C [S10140/S10141 series (-01)] Operating frequency 2.5 MHz, temperature 0 °C (S13240/S13241 series)

\*13: Dynamic range=Saturation charge/Readout noise

\*14: Measured at one-half of the saturation output using LED light (peak emission wavelength: 470 nm)

Fixed pattern noise (peak to peak) Photoresponse nonuniformity = × 100 [%]

Signal

\*15: White spots


Pixels whose dark current is higher than 1 ke after one-second integration at a cooling temperature of 0 °C Black spots

Pixels whose sensitivity is lower than one half of the average pixel output (measured with uniform light producing one-half of the saturation charge)

\*16: 2 to 9 consecutive image defects


\*17: 10 or more consecutive image defects






#### Spectral response (without window)\*18

\*18: Spectral response with quartz glass or AR-coated sapphire are decreased according to the spectral transmittance characteristics of window material.





#### Dark current vs. temperature



KMPDB0255EB








Note: When viewed from the direction of the incident light, the horizontal shift register is covered with a thick silicon layer (dead layer). However, long-wavelength light passes through the silicon dead layer and may possibly be detected by the horizontal shift register. To prevent this, provide light shield on that area as needed.

KMPDC0612EA






Note: When viewed from the direction of the incident light, the horizontal shift register is covered with a thick silicon layer (dead layer). However, long-wavelength light passes through the silicon dead layer and may possibly be detected by the horizontal shift register. To prevent this, provide light shield on that area as needed.

KMPDC0613EA



#### Timing chart




Dar	Parameter			S1324	0/S13241	series	S10140/	S10141 sei	ries (-01)	Unit
Pdi	ameter		Symbol	Min.	Тур.	Max.	Min.	Тур.	Max.	Unit
	Dulco	-1107 (-01)		0.75	1	-	3	4	-	
P1V, P2V, TG*19	Pulse width	-1108 (-01)	Tpwv	1.5	2	-	6	8	-	μs
FIV, FZV, TG <sup>23</sup>	widen	-1109 (-01)		3	4	-	12	16	-	
	Rise and fa	all times	Tprv, Tpfv	20	-	-	20	-	-	ns
	Pulse width		Tpwh	50	200	-	1000	2000	-	ns
P1H, P2H*19	Rise and fa	Rise and fall times		10	-	-	10	-	-	ns
	Duty ratio		-	40	50	60	40	50	60	%
	Pulse width	า	Tpws	50	200	-	1000	2000	-	ns
SG	Rise and fa	all times	Tprs, Tpfs	10	-	-	10	-	-	ns
	Duty ratio		-	40	50	60	40	50	60	%
DC	Pulse width	Pulse width		10	40	-	100	1000	-	ns
RG	Rise and fa	all times	Tprr, Tpfr	5	-	-	5	-	-	ns
TG – P1H	Overlap tin	ne	Tovr	1	2	-	1	2	-	μs

\*19: Symmetrical clock pulses should be overlapped at 50% of maximum pulse amplitude.




8

#### Dimensional outline (unit: mm)



KMPDA0567EA





S13241 series, S10141 series (-01)

Weight: 38.7 g

KMPDA0356EA



#### Pin connections

Pin		S13240 series		S13241 series	Remark
No.	Symbol	Function	Symbol	Function	(standard operation)
1	RD	Reset drain	RD	Reset drain	+16 V
2	OS	Output transistor source	OS	Output transistor source	RL=2.2 kΩ
3	OD	Output transistor drain	OD	Output transistor drain	+16 V
4	OG	Output gate	OG	Output gate	+5 V
5	SG	Summing gate	SG	Summing gate	Same timing as P2H
6	Vret	Output amplifier return	Vret	Output amplifier return	+4 V
7	-		-		
8	P2H	CCD horizontal register clock-2	P2H	CCD horizontal register clock-2	
9	P1H	CCD horizontal register clock-1	P1H	CCD horizontal register clock-1	
10	IG2H	Test point (horizontal input gate-2)	IG2H	Test point (horizontal input gate-2)	-9 V
11	IG1H	Test point (horizontal input gate-1)	IG1H	Test point (horizontal input gate-1)	-9 V
12	ISH	Test point (horizontal input source)	ISH	Test point (horizontal input source)	Connect to RD
13	TG*20	Transfer gate	TG*20	Transfer gate	Same timing as P2V
14	P2V	CCD vertical register clock-2	P2V	CCD vertical register clock-2	
15	P1V	CCD vertical register clock-1	P1V	CCD vertical register clock-1	
16	-		Th1	Thermistor	
17	-		Th2	Thermistor	
18	-		P-	TE-cooler (-)	
19	-		P+	TE-cooler (+)	
20	SS	Substrate (GND)	SS	Substrate (GND)	GND
21	RD	Reset drain	RD	Reset drain	+16 V
22	IG2V	Test point (vertical input gate-2)	IG2V	Test point (vertical input gate-2)	-9 V
23	IG1V	Test point (vertical input gate-1)	IG1V	Test point (vertical input gate-1)	-9 V
24	RG	Reset gate	RG	Reset gate	

\*20: Isolation gate between vertical register and horizontal register. In standard operation, TG should be applied the same pulse as P2V.

Pin		S10140 series (-01)		S10141 series (-01)	Remark
No.	Symbol	Function	Symbol	Function	(standard operation)
1	RD	Reset drain	RD	Reset drain	+15 V
2	OS	Output transistor source	OS	Output transistor source	RL=22 kΩ
3	OD	Output transistor drain	OD	Output transistor drain	+22 V
4	OG	Output gate	OG	Output gate	+5 V
5	SG	Summing gate	SG	Summing gate	Same timing as P2H
6	-		-		
7	-		-		
8	P2H	CCD horizontal register clock-2	P2H	CCD horizontal register clock-2	
9	P1H	CCD horizontal register clock-1	P1H	CCD horizontal register clock-1	
10	IG2H	Test point (horizontal input gate-2)	IG2H	Test point (horizontal input gate-2)	-9 V
11	IG1H	Test point (horizontal input gate-1)	IG1H	Test point (horizontal input gate-1)	-9 V
12	ISH	Test point (horizontal input source)	ISH	Test point (horizontal input source)	Connect to RD
13	TG*21	Transfer gate	TG*21	Transfer gate	Same timing as P2V
14	P2V	CCD vertical register clock-2	P2V	CCD vertical register clock-2	
15	P1V	CCD vertical register clock-1	P1V	CCD vertical register clock-1	
16	-		Th1	Thermistor	
17	-		Th2	Thermistor	
18	-		P-	TE-cooler (-)	
19	-		P+	TE-cooler (+)	
20	SS	Substrate (GND)	SS	Substrate (GND)	GND
21	RD	Reset drain	RD	Reset drain	+15 V
22	IG2V	Test point (vertical input gate-2)	IG2V	Test point (vertical input gate-2)	-9 V
23	IG1V	Test point (vertical input gate-1)	IG1V	Test point (vertical input gate-1)	-9 V
24	RG	Reset gate	RG	Reset gate	


\*21: Isolation gate between vertical register and horizontal register. In standard operation, TG should be applied the same pulse as P2V.



#### Specifications of built-in TE-cooler (Typ.)

Parameter	Symbol	Condition	S13241 series, S10141 series (-01)	Unit
Internal resistance	Rint	Ta=25 °C	1.2	Ω
Maximum heat absorption*22	Qmax		5.1	W

\*22: This is a theoretical heat absorption level for correcting the temperature difference that occurs in the thermoelectric cooler when the maximum current is supplied.



To make the cooling side -10 °C, the temperature on the heat radiation side must be 30 °C or less. As a guideline, use a heatsink whose thermal resistance is no more than 1 °C /W.


#### Specifications of built-in temperature sensor

A thermistor chip is built into the same package with a CCD chip and monitors the operating CCD chip temperature. The relation between this thermistor's resistance and absolute temperature is express by the following equation.

 $R_{T1} = R_{T2} \times exp B_{T1/T2} (1/T1 - 1/T2)$ 

RT1: resistance at absolute temperature T1 [K] RT2: resistance at absolute temperature T2 [K] BT1/T2: B constant [K]

The characteristics of the thermistor used are as follows. R298=10 k $\Omega$  B298/323=3450 K



KMPDB0111EB



#### Precautions (electrostatic countermeasures)

- · Handle these sensors with bare hands or wearing cotton gloves. In addition, wear anti-static clothing or use a wrist band with an earth ring, in order to prevent electrostatic damage due to electrical charges from friction.
- · Do not place the sensor directly on workbenches or floors that may become charged with static electricity.
- · Connect a ground wire to workbenches or floors in order to discharge static electricity.
- · Ground tools, such as tweezers and soldering irons, that are used to handle the sensor.

It is not always necessary to provide all the electrostatic countermeasures stated above. Implement these countermeasures according to the extent of deterioration or damage that may occur.

#### Temperature gradient rate for cooling or heating of element

When using an external cooler, set the temperature gradient rate for cooling or heating the element to 5 K/minute or less.

#### Related information

www.hamamatsu.com/sp/ssd/doc\_en.html

- Precautions
- Disclaimer
- Image sensors

Technical information

- · FFT-CCD area image sensor/Technical information
- Image sensors/Terminology

Information described in this material is current as of December 2016.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.



#### www.hamamatsu.com

#### HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81) 53-434-3311, Fax: (81) 53-434-5184

U.S.A.: Hamamatsu Corporation: 360 Foothill Road, Bridgewater, N.J. 08807, U.S.A., Telephone: (1) 908-231-0960, Fax: (1) 908-231-1218 Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany, Telephone: (49) 8152-375-0, Fax: (49) 8152-265-8

France: Hamanatsu Photonics France S.A.R.L.: 19, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Tielphone: 33-(1) 69 53 71 00, Fax: 33-(1) 69 53 71 10 United Kingdom: Hamamatsu Photonics UK Limited: 2 Howard Court, 10 Tewin Road, Welwyn Garden City, Hertfordshire AL7 1BW, United Kingdom, Telephone: (44) 1707-294888, Fax: (44) 1707-325777 North Europe: Hamamatsu Photonics Norden AB: Torshamnsgatan 35 16440 Kista, Sweden, Telephone: (46) 8-509-031-00, Fax: (46) 8-509-031-01

Italy: Hamamatsu Photonics Italia S.r.l.: Strada della Moia, 1 int. 6, 20020 Arese (Milano), Italy, Telephone: (39) 02-93581733, Fax: (39) 02-93581741 China: Hamamatsu Photonics (China) Co., Ltd.: B1201, Jiaming Center, No.27 Dongsanhuan Beilu, Chaoyang District, Beijing 100020, China, Telephone: (86) 10-6586-6006, Fax: (86) 10-6586-2866

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.