

GATED MCP-PMT UNIT C13068

FEATURES

- ●High detection efficiency
- ●Excellent time resolution
- ●Low gate induced noise

APPLICATIONS

- SLR (Satellite Laser Ranging)
- General laser ranging

Figure 1: Typical instrument response function (I.R.F.)




Figure 3: Spectral response





Figure 2: Block diagram of I.R.F. (Instrument Response Function) measuring apparatus



TPMOC0280EA

Subject to local technical requirements and regulations, availability of products included in this promotional material may vary. Please consult with our sales office. Information furnished by HAMAMATSU is believed to be reliable. However, no responsibility is assumed for possible inaccuracies or omissions. Specifications are subject to change without notice. No patent rights are granted to any of the circuits described herein. ©2017 Hamamatsu Photonics K.K.

GATED MCP-PMT UNIT C13068

SPECIFICATIONS

GENERAL

Parameter		Description / Value	Unit
Spectral response range		280 to 720	nm
Wavelength of peak quantum efficiency range		480 to 530	nm
Input window	Material	Borosilicate glass	_
Photocathode	Material	GaAsP	_
	Minimum effective diameter	10	mm
AC input		100 to 240	V

MAXIMUM RATINGS

Parameter	Description / Value	Unit
Supply voltage ^(A)	-2200	V
Average anode current	100	nA
Pulsed peak current	350	mA
Ambient temperature (Operating and storage)	0 to +40	°C

CHARACTERISTICS

Parameter		Min.	Тур.	Max.	Unit
Photocathode sensitivity	Luminous sensitivity ®	400	700	_	μA/lm
	Quantum efficiency at 532 nm ©	30	40	_	%
Gain (at -2000 V)		4.0×10^{5}	_	_	_
Anode dark count (+25 °C) ®		_	1.0 × 10 ⁴	5.0 × 10 ⁵	S ⁻¹
	Rise time [©]	_	180	_	
Time response	Fall time ^(F)	_	400	_	ps
	I.R.F. (FWHM) [©]	_	80	_	

GATING CHARACTERISTICS

Parameter		Description / Value	Unit	
Gate input signal	Signal level	Gate on: +5 / Gate off: 0	V	
	Repetition frequency (Max.)	5	kHz	
	Impedance	50	Ω	
Gating time		100 ns to 50 μs	_	

- **NOTE:** (A) The supply voltage will be determined between -1800 V to -2200 V in order to satisfy the specification for luminous gain. This value is referred on the test data sheet for each tube.
 - ®The light source used to measure the luminous sensitivity is a tungsten filament lamp operated at a distribution temperature of 2856 K. The incident light intensity is 10⁻⁴ Im and 100 V is applied between the photocathode and all other electrodes connected as an anode.
 - ©Measured at the peak sensitivity wavelength.
 - DAt 30 min after high voltage is applied
 - EThis is the mean time difference between the 10 % and 90 % amplitude points on the output waveform for full cathode illumination.
 - ©This is the mean time difference between the 90 % and 10 % amplitude points on the tailing edge of the output waveform for full cathode illumination.
 - ©IRF stands for Instrument Response Function which is a convolution of the δ pulse function (H(t)) of the measuring system and the excitation function (E(t)) of a laser. The I.R.F. is given by the following formula:

I.R.F. = $H(t) \times E(t)$

We specify the I.R.F. as an FWHM of the time distribution taken by using the measuring system in Figure 2 that is Hamamatsu standard IRF measurement. It can be temporary estimated by the following equation:

 $(I.R.F. (FWHM))^2 = (T.T.S.)^2 + (Tw)^2 + (Tj)^2$

where Tw is the pulse width of the laser used and Tj is the time jitter of all equipments used. An I.R.F. data is provided with the tube purchased as a standard.

Transit-time spread (T.T.S.) is the fluctuation in transit time between individual pulse and specified as an FWHM (full width at half maximum) with the incident light having a single photoelectron state.

Figure 4: Typical gain






Figure 5: Dimensional outline (Unit: mm)



* The height is 120 mm with front legs extended.

GATED MCP-PMT UNIT C13068

Figure 6: Connection example



ACCESSORIES

HIGH SPEED AMPLIFIER C5594 Series

Suffix number and input / output connector

Type No.	Input connector	Output connector
C5594-12	SMA plug (male)	SMA receptacle (female)
C5594-22	SMA receptacle (female)	SMA receptacle (female)
C5594-44	BNC receptacle (female)	BNC receptacle (female)



Specifications

Parameter		Description / Value	
Frequency response range		50 kHz to 1.5 GHz	
Voltage gain Typ.		36 dB	
Current-to-Voltage conversion factor		3.15 mV/A	
Input / Output impedance		50 Ω	
Noise figure (NF)		5 dB	
Supply voltage		+12 V to 16 V	
Supply current	Max.	95 mA	

HAMAMATSU PHOTONICS K.K. www.hamamatsu.com