

Photon counting module

C14076-01

Fiber coupling type, low-light-level detection

The C14076-01 is a photon counting module that can detect low-level light. It consists of a TE-cooled single pixel photon counter (SPPC), amplifier, comparator, high-voltage power supply circuit, and temperature controller. This product is a fiber coupling type module. The module operates by supplying an external power supply (±5 V). As this product is compact and lightweight, it is suitable for integration into devices.

Features

- ➡ Fiber coupling type
- **■** Single photon counting is possible.
- → High short-wavelength sensitivity
- **■** Low dark count
- Compact and lightweight

Applications

- **→** Low-level-light measurement
- Particle diameter measurement
- ⇒ Fluorescence measurement
- → Analytical instruments

- Absolute maximum ratings

Parameter	Symbol	Condition	Value	Unit
Supply voltage	Vs		±6	V
Operating temperature	Topr	No dew condensation*1	-10 to +40	°C
Storage temperature	Tstg	No dew condensation*1	-20 to +70	°C
Maximum incident light level	-	λ=450 nm	50	μW

^{*1:} When there is a temperature difference between a product and the surrounding area in high humidity environment, dew condensation may occur on the product surface. Dew condensation on the product may cause deterioration in characteristics and reliability.

Recommended operating conditions

	Parameter	Symbol	Min.	Тур.	Max.	Unit
Supply	Positive power supply	Vs	4.75	5	5.25	V
voltage*2	Negative power supply		-4.75	-5	-5.25	

^{*2:} A power supply with 2 A or higher output must be used.

Electrical and optical characteristics (Ta=25 °C, λ=450 nm, Vs=±5 V, unless otherwise noted)

Parameter	Symbol	Condition	Min.	Тур.	Max.	Unit
Spectral response range	λ		370 to 900		nm	
Peak sensitivity wavelength	λр		-	450	-	nm
Fiber connector*3	-		FC type		-	
Chip temperature (setting temperature)*4 *5	Tchip		-	-20	-	°C
Photon detection efficiency	PDE		35	45	-	%
Dark count	CD		-	7	25	cps
Afterpulse probability	-	100 ns to 500 ns	-	0.1	-	%
Comparator output	-		TTL compatible			-
Current consumption +5 V -5 V	Ic		-	+200	+1500	mA
			-	-20	-40	


^{*3:} Recommended fiber: GI 50/125 multimode fiber

Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.

^{*4:} When the chip temperature strays from the setting temperature by 5 °C, cooling automatically stops, and signals are no longer output.


^{*5:} The setting temperature cannot be changed.

Block diagram




Connection example

Using the supplied power cable, connect the module to a power supply. You can count output pulses by connecting the module to a frequency counter.



HAMAMATSU


Measurement example




Photon detection efficiency vs. wavelength (typical example)

(Ta=25 °C) Photon detection efficiency (%) 40 30 20 10 700 300 400 500 600 800 900 Wavelength (nm) KACCB0464EA

Linearity (typical example)



Dimensional outline (unit: mm)



Note: When using this product, provide heat dissipation measures by using heatsinks or through thermal coupling with the enclosure that you will use. Keep the thermal resistance to 3 °C/W or less.

Accessories

- · Power cable
- · Instruction manual

Precautions

 \cdot Use the product by referring to the supplied instruction manual.

- Related products

Photon counting module C13001-01

The C13001-01 is a module for evaluating fiber coupling type single pixel photon counters (SPPCs). This module consists of a fiber coupling type SPPC, amplifier, comparator, high-voltage power supply circuit, and temperature controller. The module operates by supplying an external power supply (±5 V). The C13001-01 series has nearly the same functions as the C14076-01. Note that the C13001-01 does not require heat dissipation measures.



Related information

http://www.hamamatsu.com/sp/ssd/doc_en.html

- Precautions
- Disclaimer

Information described in this material is current as of February 2019.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

AMAMATSU

www.hamamatsu.com

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81)53-434-3311, Fax: (81)53-434-5184

U.S.A.: Hamamatsu Corporation: 360 Footbill Road, Bridgewater, N.J. 08807, U.S.A., Telephone: (1)908-231-0960, Fax: (1)908-231-1218, E-mail: usa@hamamatsu.com

Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany, Telephone: (49)8152-375-0, Fax: (49)8152-265-8, E-mail: info@hamamatsu.de

France: Hamamatsu Photonics France S.A.R.L.: 19, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy, Cedex, France, Telephone: (43)1 69 53 71 00, Fax: (33)1 69 53 71 10, E-mail: info@hamamatsu.fr

United Kingdom: Hamamatsu Photonics Norden AB: Torshamnsgatan 35 16440 Kista, Sweden, Telephone: (46)8-509 031 00, Fax: (46)8-509 031 01, E-mail: info@hamamatsu.se

Italy: Hamamatsu Photonics Italia S.r.l.: Strada della Moia, 1 int. 6, 20020 Arese (Milano), Italy, Telephone: (39)02-93 58 17 33, Fax: (39)02-93 58 17 41, E-mail: info@hamamatsu.it

China: Hamamatsu Photonics (China) Co., Ltd.: B1201, Jiaming Center, No.27 Dongsanhuan Bellu, Chaoyang District, 100020 Beijing, P.R.China, Telephone: (86)10-6586-6006, Fax: (86)10-6586-2866, E-mail: hpc@hamamatsu.com.cn

Taiwan: Hamamatsu Photonics Taiwan Co., Ltd.: 8F-3, No. 158, Section2, Gongdao 5th Road, East District, Hsinchu, 300, Taiwan R.O.C. Telephone: (86)3-659-0081, E-mail: info@hamamatsu.com.cn