


Photo IC for laser beam synchronous detection



S9703-11

High sensitivity, high-speed response

The S9703-11 photo IC uses a high-speed PIN photodiode designed for laser beam synchronous detection. When compared to the S9703-01 previously marketed, the S9703-11 has reduced their reflection effects in the package. Tape-and-reel shipment (S9703-31) is available. Hamamatsu also provides the S9684 series photo ICs that use a dualelement Si PIN photodiode.

Features

- High sensitivity **Current amplifier gain: 6 times**
- Digital output
- Small package
- **■** Suitable for lead-free solder reflow
- → Photosensitive area: 2.84 × 0.5 mm

Applications

Print start timing detection for laser printers, digital copiers, fax machines, etc.

Absolute maximum ratings

Parameter	Symbol	Condition	Value	Unit
Supply voltage	Vcc	Ta=25 °C	-0.5 to +7	V
Power dissipation*1	Р	Ta=25 °C	300	mW
Output voltage*2	Vo	Ta=25 °C	-0.5 to +7	V
Output current	Io	Ta=25 °C	5	mA
Ro terminal current	IRO	Ta=25 °C	3	mA
Operating temperature	Topr	No condensation	-25 to +80	°C
Storage temperature	Tstg	No condensation	-40 to +85	°C
Reflow soldering conditions	Tsol	JEDEC MSL 5a	Peak temperature: 240 °C max., 1 time	-

^{*1:} Power dissipation decreases at a rate of 4 mW/°C above Ta=25 °C.


Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.

^{*2:} Vcc=+0.5 V or less


E Electrical and optical characteristics (Ta=25 °C, λ=780 nm, Vcc=5 V, Ro=5.1 kΩ, unless otherwise noted)

Parameter	Symbol	Condition	Min.	Тур.	Max.	Unit
Current consumption	Icc	No input	-	0.9	1.5	mA
High level output voltage	Voн	IOH=4 mA	4.6	-	-	V
Low level output voltage	Vol	IoL=4 mA PI=225 μW	-	-	0.3	V
Threshold input power	Ртн		60	75	90	μW
H→L propagation delay time	tphl	PI=225 µW Duty ratio 1:1 CL=15 pF* ³	-	75	150	ns
L→H propagation delay time	tplh		-	150	200	
Rise time	tr		-	4	7	ns
Fall time	tf		-	4	7	ns
Maximum input power	PI max		-	-	Ртн × 8	μW

^{*3:} Measured with a pulse-driven laser diode. Rise time and fall time of input light-pulse are 1 ns or less.




- Spectral response



HAMAMATSU PHOTON IS OUR BUSINESS

Block diagram



Function

The S9703-11 photo IC integrates a photodiode chip and an IC chip into the same package. The photodiode chip is internally connected to the IC chip as shown in the block diagram. The S9703-11 should be used with terminal Ro connected to an external gain resistance Ro. A photocurrent is generated when a laser beam enters the photodiode. This photocurrent is fed to the input terminal of the IC and, after being amplified by the current amplifier, flows to the external gain resistance. At this time, voltages VRO at terminal Ro is given by the following expression.

 $VRO=A \times S \times PI \times Ro [V] \cdots (1)$

A: Current amplifier gain (6 times)

S: Photodiode sensitivity [A/W] (approx. 0.44 A/W at 780 nm)


PI: Input power [W]

Ro: External gain resistance $[\Omega]$; usable range 2 k Ω to 10 k Ω

VRO is input to the internal comparator and compared with the internal reference voltage Vref (approx. 1 V) so the output Vo is "High" when VRO < Vref or "Low" when VRO > Vref.


In equation (1), set the Ro value so that VRO will be 2 to 3 V.

Dimensional outline (unit: mm)




KPICA0071EA

- Recommended land pattern (unit: mm)



Recommended reflow soldering conditions

The S9703-11 supports lead-free soldering. After unpacking, store them in an environment at a temperature of 30 °C or less and a humidity of 60% or less, and perform soldering within 24 hours.



Time

KPICB0171EA

Related information

www.hamamatsu.com/sp/ssd/doc_en.html

- Precautions
- Notice
- · Surface mount type products / Precautions

Information described in this material is current as of February 2020.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

HAMAMATSU

www.hamamatsu.com

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81)53-434-3311, Fax: (81)53-434-5184

1120-1 ICHINO-CTIO, HIgdstNi-Ku, Harmamatsu City, 435-6558 Japahi, Telephone: (1)908-231-0960, Fax: (1)908-231-1218, E-mail: usa@hamamatsu.com
Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany, Telephone: (49)8152-375-0, Fax: (49)8152-265-8, E-mail: info@hamamatsu.de
France: Hamamatsu Photonics France S.A.R.L.: 19, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy, Cedex, France, Telephone: (49)8152-375-0, Fax: (49)8152-265-8, E-mail: info@hamamatsu.de
United Kingdom: Hamamatsu Photonics France S.A.R.L.: 19, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy, Cedex, France, Telephone: (33)1 69 53 71 00, Fax: (33)1 69 53 71 10, E-mail: info@hamamatsu.de
United Kingdom: Hamamatsu Photonics Norden AB: Torshamnsgatan 35 16440 Kista, Sweden, Telephone: (46)8-509 031 00, Fax: (46)8-509 031 01, E-mail: info@hamamatsu.se
Italy: Hamamatsu Photonics (Italia S.n.l.: Strada della Moia, 1 int. 6, 20020 Arese (Milano), Italy, Telephone: (49)902-93 58 17 3, Fax: (49)10-6586-6006, Fax: (66)10-6586-2866, E-mail: hpc@hamamatsu.de
China: Hamamatsu Photonics (China) Co., Ltd.: B1201, Jiaming Center, No.27 Dongsanhuan Beilu, Chaoyang District, 100020 Beijing, P.R.China, Telephone: (86)10-6586-6006, Fax: (86)10-6586-2866, E-mail: hpc@hamamatsu.com.cn
Taiwan: Hamamatsu Photonics Taiwan Co., Ltd.: 8F-3, No. 158, Section2, Gongdao 5th Road, East District, Hsinchu, 300, Taiwan R.O.C. Telephone: (86)3-659-0081, E-mail: info@hamamatsu.com.cn