

# PHOTON IS OUR BUSINESS

# **One-dimensional PSD**

Plastic package

# 1-D PSD with small plastic package

Hamamatsu offers a variety of 1-D PSDs (position sensitive detectors) molded into plastic packages. These PSDs feature excellent position detection resolution, high resistance to disturbance background light and high reliability.

### Features

- **Excellent position detection resolution**
- → High reliability
- Thin, miniature plastic package
- Clear package passing wide wavelength range or visible-cut package reducing background light noise
- Surface mount packages are available.
- High interelectrode resistance: S3274-05, S7105-05, S5629-02

# Applications

- Auto focus camera
- Range finders
- Optical proximity switches
- Displacement meters

# Structure / Absolute maximum ratings

		Dimensional outline			Absolute maximum ratings				
Type no.	Package		Photosensitive area	Resistance length	Reverse voltage VR max	Operating temperature Topr	Storage temperature Tstg		
			(mm)	(mm)	(V)	(°C)	(°C)		
S4581-04		(1)	1 × 2	2		-25 to +85	-40 to +100		
S4583-04	Surface mount type, visible-cut	(1)	1 × 3	3					
S4584-04		(1)	1 × 3.5	3.5	20				
S4584-06	Surface mount type, clear								
S3274-05	DIP type, visible-cut	(2)							
S7105-04	Surface mount type, visible-cut		1 × 4.2	4.2					
S7105-06	Surface mount type, clear								
S7105-05	Curface mount type visible out								
S5629	Surface mount type, visible-cut	(4)	1 × 6						
S5629-01	Surface mount type, clear			6					
S5629-02	Surface mount type, visible-cut								

Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.


This product does not support lead-free soldering. For details on reflow soldering conditions for surface-mount components, please contact our sales office.

# **■** Electrical and optical characteristics (Typ. Ta=25 °C, unless otherwise noted)


Type no.	Spectral response range λ	Peak sensitivity wavelength $\lambda p$	Photosensitivity S		Interelectrode resistance Rie Vb=0.1 V		Position detection error *1 VR=1 V Light spot size=\p300 \mum		*2 Tet	Dark current ID VR=1 V		Temp. coefficient of ID TCID	Rise time *3 tr $V_{R=1}$ $V$ $V_{L=1}$ $V_{L=1}$		Terminal capacitance Ct VR=1 V	
			λ=650 nm	λ=890 nm	Min.	Тур.	Max.	Тур.	Max.	RL=1 k $\Omega$	Тур.	Max.	ICID	λ=650 nm	λ=890 nm	1-10 KHZ
	(nm)	(nm)	(A/W)	(A/W)	$(k\Omega)$	$(k\Omega)$	$(k\Omega)$	(µm)	(µm)	(µA)	(nA)	(nA)	(times/°C)	(µs)	(µs)	(pF)
S4581-04	760 to 1060	920	-	0.51	100	140	180	±10	±20	30	0.05	1	1.15	-	10	15
S4583-04	760 to 1100	960	-	0.51	100	140	180	±10	±30	30	0.05	1	1.15	-	10	15
S4584-04	760 to 1100	960	-		100	140	180			30				-	10	
S4584-06	320 to 1100		0.33	0.51	140	100	±15	±35	30	0.05	1	1.15	3	10	15	
S3274-05	760 to 1100		-		320	400	480			15				-	15	]
S7105-04	760 to 1100	960	-	0.51	100 140	140	100			30				-	5 .	
S7105-06	320 to 1100		0.38	0.55		180	±15	±40	30	0.1	2	1.15	2	] 3	40	
S7105-05	760 to 1100		-	0.51	320	400	480			15				-	10	
S5629	760 to 1100	960	-	0.51	30 50	Ε0	00			00				-	_	
S5629-01	320 to 1100		0.38	0.55		80	±20	±60	80	0.1	2	1.15	2	5	60	
S5629-02	760 to 1100		-	0.51	240	300	360			20				-	10	<u> </u>

<sup>\*1:</sup> In the range 75% from the center of the photosensitive area to the edge

# Spectral response



# Dark current vs. reverse voltage




<sup>\*2:</sup> This indicates the upper limit of the photocurrent linearity over the entire incident light quantity and is defined as the photocurrent at a point where the linearity deviates by 10%.

<sup>\*3:</sup> Time required for output change from 10 to 90% of the steady output value when stepped function light is input to the PSD

# **One-dimensional PSD**

# Plastic package

## **Saturation photocurrent vs. interelectrode resistance**




Interelectrode resistance ( $k\Omega$ )

# - Definition of position detection error

When the electrical center of a PSD is assumed to be the position of incident light where light current I1 equals I2, position detection error at each incident position can be defined by the following equation.

Position detection error (µm) = Incident position -  $\frac{I2 - I1}{I1 + I2} \times \frac{L}{2}$ 


The electrical center is viewed as 0, I1 as (+), and I2 as (-).




KPSDB0003EA

# - Dimensional outlines (unit: mm)

(1) S4581-04, S4583-04, S4584-04/-06 (Surface mount type)






- 5.0 ± 0.2 (Including burr) 8.0 5.0 8.0 5.0 8.0 4.8\*
  - ① Anode 1
  - ② Cathode (common)
  - ③ Anode 2
  - 4 Cathode (common)

Tolerance unless otherwise noted:  $\pm 0.1$ 

Position accuracy of photosensitive area center with respect to the package dimensions marked \*  $X,Y \le \pm 0.2$   $\theta \le \pm 2^{\circ}$ 


KPSDA0022EA

# (2) S3274-05




KPSDA0063EA

# (3) S7105-04/-05/-06 (Surface mount type)



KPSDA0047EA

### (4) S5629/-01/-02 (Surface mount type)



θ≤±2°

KPSDA0023EA

### Related information

www.hamamatsu.com/sp/ssd/doc\_en.html

- Precautions
  - Notice
  - · Metal, ceramic, plastic package products/Precautions
  - · Surface mount type products/Precautions
- Technical information
  - · PSD/Technical information

Information described in this material is current as of September, 2013.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

Type numbers of products listed in the delivery specification sheets or supplied as samples may have a suffix "(X)" which means preliminary specifications or a suffix "(Z)" which means developmental specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use.

Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

# HAMAMATSU

www.hamamatsu.com

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81) 53-434-3311, Fax: (81) 53-434-5184
U.S.A.: Hamamatsu Corporation: 360 Foothill Road, P.O.Box 6910, Bridgewater, N.J. 08807-0910, U.S.A., Telephone: (1) 908-231-0960, Fax: (1) 908-231-1218
Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany, Telephone: (49) 8152-375-0, Fax: (49) 8152-265-8
France: Hamamatsu Photonics France S.A.R.L.: 19, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: 33-(1) 69 53 71 00, Fax: 33-(1) 69 53 71 00
United Kingdom: Hamamatsu Photonics UK Limited: 2 Howard Court, 10 Tewin Road, Welwyn Garden City, Hertfordshire AL7 1BW, United Kingdom, Telephone: (44) 1707-294888, Fax: (44) 1707-325777
North Europe: Hamamatsu Photonics Norden AB: Thorshamnsgatan 35 16440 Kista, Sweden, Telephone: (46) 8-509-031-00, Fax: (36) 8-509-031-01
Italy: Hamamatsu Photonics Italia S.R.L.: Strada della Moia, 1 int. 6, 20020 Arese, (Milano), Italy, Telephone: (39) 02-935-81-733, Fax: (39) 02-935-81-741
China: Hamamatsu Photonics (China) Co., Ltd.: 1201 Tower B, Jiaming Center, No.27 Dongsanhuan Beilu, Chaoyang District, Beijing 100020, China, Telephone: (86) 10-6586-6006, Fax: (86) 10-6586-2866